

Driver circuit for MPPC®



C12332-02

Simple evaluation driver circuit for non-cooled MPPC

The C12332-02 is a driver circuit for simple evaluation of non-cooled MPPC and power supply C11204-01 for MPPC. MPPC evaluation is possible by mounting an MPPC in the socket of the sensor circuit board. Various types of MPPCs can be evaluated. MPPC with flexible cable (for evaluating surface mount type MPPC) can also be connected by using the FFC connector of the power supply circuit board. The PZC (pole-zero cancellation) circuit is built-in to reduce the falling edge decay time of MPPC. The power supply circuit board is equipped with the power supply C11204-01 that provides the operating voltage for MPPC. It operates just by connecting to an external power supply (±5 V). It is also equipped with a USB interface that can be used to set the MPPC supply voltage and temperature compensation coefficient from a PC running the supplied sample software.

Features

- **■** Enables the evaluation of non-cooled MPPC
- Sensor circuit board with a socket for mounting an MPPC with leads
- **■** Connection possible to MPPC with flexible cable
- **Equipped with high-accuracy power supply C11204-01**
- **MPPC** supply voltage and temperature compensation coefficient can be set from PC.
- ⇒ Selectable amplifier usage (default setting: used)
- \blacksquare Selectable load resistance 50 Ω or 1 k Ω
- Built-in PZC circuit (default setting: PZC constant is set to S13360-3050CS)
- Analog output

Note: MPPC is sold separately.

- Applications

■ Simple initial evaluation of MPPC

- Compatible MPPCs

Type no.	Number of channels (ch)	Effective photosensitive area (mm)	Pixel pitch (µm)	Number of pixels
S13360-1325CS			25	2668
S13360-1350CS		1.3 × 1.3	50	667
S13360-1375CS	1		75	285
S13360-3025CS		3 × 3	25	14400
S13360-3050CS			50	3600
S13360-3075CS			75	1600
S13360-6025CS		6 × 6	25	57600
S13360-6050CS			50	14400
S13360-6075CS			75	6400

■ Absolute maximum ratings

Parameter	Symbol	Condition	Specification	Unit
Supply voltage	Vs		±5.8	V
Operating temperature	Topr	No dew condensation*1	-20 to +60	°C
Storage temperature	Tstg	No dew condensation*1	-20 to +80	°C

^{*1:} When there is a temperature difference between a product and the surrounding area in high humidity environments, dew condensation may occur on the product surface. Dew condensation on the product may cause deterioration in characteristics and reliability.

♣ Recommended operating conditions (Ta=25 °C, unless otherwise noted)

Parameter	Symbol	Condition	Min.	Тур.	Max.	Unit
Supply voltage*2	Vs		±4.75	±5	±5.25	V
Load resistance*3	RL	When amplifier is not used	-	50 or 1 k	-	Ω


^{*2:} Use a power supply with 300 mA or higher output.

■ Electrical characteristics (Ta=25 °C, Vs=±5 V, unless otherwise noted)

Parameter	r	Symbol	Condition	Min.	Typ.	Max.	Unit
Current consumption		IC	Vo=72 V, no load, when +5 V	+36	+48	+60	mA
			communicating with a PC -5 V	-10	-15	-20	
MPPC supply voltag	e range*4	Vo	No load	-	20 to 80	-	V
Setting voltage reso	olution*5	-		-	10	-	mV
Setting voltage erro	r	-	Vo=72 V, no load	-	±10	±40	mV
Voltage monitor err	or	-	Vo=72 V, no load	-	±10	-	mV
Current monitor err	or	-	Vo=72 V, Io=1.0 mA	- ±0.05 -		-	mA
Cutoff frequency	High		When amplifier (gain: 20) is used, RL=50 Ω , -3 dB	-	40	-	MHz
	Low			-	DC	-	
PZC constant*6		-		Set for S13360-3050CS		-	
Mounted temperatu	ire sensor	-		LM94021BIMG (Texas Instruments)		-	
Interface*7		-		USB 2.0 (Full Speed)		-	

^{*4:} The MPPC operating voltage varies depending on the product. Refer to the value provided with the product.

Block diagram



KACCC0986EA



Note: Exceeding the absolute maximum ratings even momentarily may cause a drop in product quality. Always be sure to use the product within the absolute maximum ratings.


^{*3:} The default setting is 50 Ω . When using an amplifier, set the load resistance to 50 Ω .

^{*5:} When the sample software is used


^{*6:} The default setting is "Amplifier \rightarrow PZC circuit" jumper.

^{*7:} After you set the operating voltage, remove the USB cable from the driver circuit for MPPC to eliminate any noise effects from the PC.

Connection example



Measure





make measurements using an oscilloscope or other device.

From the sample software, disconnect the communication with the PC, remove the USB cable, and

ightharpoonup Measurement examples [using amplifier, gain: approx. 20x (default setting), RL=50 Ω]


Dark state 513360-1350CS ■ S133






Impulse light (wavelength: 466 nm)


■S13360-1350CS




■S13360-3050CS



Pulse light (wavelength: 470 nm, pulse width: 2 µs)




■S13360-3050CS




Reduction of falling time by PZC circuit

■ S13360-3050CS (amplifier only)



■ S13360-3050CS (amplifier → PZC circuit)




Sample software (included)

The sample software*8 is designed to simplify the MPPC evaluation. You can use the sample software to set the operating voltage and temperature compensation coefficient. The sample software has been confirmed to work with Microsoft .NET Framework 3.5 and later. The sample software was created on Microsoft® Visual Basic® 2008 Express Edition SP1.

*8: Compatible OS Microsoft® Windows® 10 (32-bit, 64-bit)


Note: Microsoft, Windows, Visual Studio, and Visual Basic are registered trademarks of Microsoft Corporation in the United States and/or other countries.



Dimensional outlines (unit: mm)

Sensor circuit board MPPC (S13360-1325CS/ MPPC (S13360-3025CS/ Analog temperature sensor -1350CS/-1375CS) -3050CS/-3075CS) Flexible cable connector (for connecting mount position mount position power supply circuit board) (2) 32 37 0 **?** \ \$ MPPC (5-pin) MPPC (S13360-6025CS/ 45 $(4 \times) \phi 2.2$ mount position -6050CS/-6075CS) 50 mount position MPPC (TO-18) mount position Tolerance unless otherwise noted: ±0.2 1.6

Power supply circuit board



KACCA0363EA

KACCA0472EA

Accessories

- · Power cable
- · Operating voltage check cable
- · USB cable
- · Flexible flat cable (50 mm)
- · CD-ROM (instruction manual, driver software, sample software, etc.)
- · Quick start guide

Precautions

- · For cleaning the product, wipe using a clean, soft, dry cloth. Do not use organic solvents such as thinner and acetone.
- · If the product and the PC are connected with a USB cable, do not remove the USB cable while the sample software is communicating.
- · This product is a simple MPPC evaluation circuit. Do not integrate this product in your device.

Options (sold separately)

Coaxial conversion adapter A10613 series

Coaxial conversion adapters for converting the SMB coaxial connector for extracting MPPC module signals into a BNC coaxial connector or an SMA coaxial connector. These adapters make connection to a BNC cable or SMA cable possible.





A10613-01 (SMB-BNC)

A10613-02 (SMB-SMA)

- Related information

http://www.hamamatsu.com/sp/ssd/doc_en.html

- Precautions
- · Disclaimer

Information described in this material is current as of November 2021.

Product specifications are subject to change without prior notice due to improvements or other reasons. This document has been carefully prepared and the information contained is believed to be accurate. In rare cases, however, there may be inaccuracies such as text errors. Before using these products, always contact us for the delivery specification sheet to check the latest specifications.

The product warranty is valid for one year after delivery and is limited to product repair or replacement for defects discovered and reported to us within that one year period. However, even if within the warranty period we accept absolutely no liability for any loss caused by natural disasters or improper product use. Copying or reprinting the contents described in this material in whole or in part is prohibited without our prior permission.

HAMAMATSU

www.hamamatsu.com

HAMAMATSU PHOTONICS K.K., Solid State Division

1126-1 Ichino-cho, Higashi-ku, Hamamatsu City, 435-8558 Japan, Telephone: (81)53-434-3311, Fax: (81)53-434-5184

U.S.A.: Hamamatsu Corporation: 360 Foothill Road, Bridgewater, N.J. 08807, U.S.A., Telephone: (1)908-231-0960, Fax: (1)908-231-1218, E-mail: usa@hamamatsu.com
Germany: Hamamatsu Photonics Deutschland GmbH: Arzbergerstr. 10, 82211 Herrsching am Ammersee, Germany, Felephone: (49)8152-375-0, Fax: (49)8152-265-8, E-mail: info@hamamatsu.de
France: Hamamatsu Photonics France S.A.R.L.: 19, Rue du Saule Trapu, Parc du Moulin de Massy, 91882 Massy Cedex, France, Telephone: (33)1 fe 95 37 10, Fax: (33)1 fe 95 37 110, E-mail: info@hamamatsu.de
France: Hamamatsu Photonics Ut Limited: 2 Howard Court, 10 Tewin Road, Welvyn Garden City, Hertfordshire AL7 18W, UK, Telephone: (44)1707-29488, Fax: (44)1707-325777, E-mail: info@hamamatsu.co.uk
North Europe: Hamamatsu Photonics Norden AB: Torshamnsgatan 35 16440 Kista, Sweden, Telephone: (79)08-590 910, Fax: (46)8-590 910 01, E-mail: info@hamamatsu.et
Italy: Hamamatsu Photonics Italia S.r.l.: Strada della Moia, 1 int. 6, 20044 Arese (Milano), Italy, Telephone: (39)02-93 58 17 33, Fax: (39)02-93 58 17 41, E-mail: info@hamamatsu.it
China: Hamamatsu Photonics Glaino Co, Ltd.: 1201 Tower B, Jiaming Center, 27 Dongsanhuan Bellu, Chaoyang District, 100020 Beijing, PR.China, Telephone: (86)10-6586-6006, Fax: (86)10-6586-2866, E-mail: hpc@hamamatsu.com.cn
Taiwan: Hamamatsu Photonics Taiwan Cs. Ltd.: 88-3, No. 158, Section2, Gongdao 5th Road, East District, Hsinchu, 300, Taiwan R.O.C. Telephone: (86)3-659-0008, Fax: (86)3-659-0081, E-mail: info@hamamatsu.com.cn